

00EPT 98828960

*Cancel*




FIG. 1

38

OVERSPEED SIGNAL	AIRCRAFT SIGNAL	NORMAL ENGINE CONTROL SIGNAL	ENGINE FUEL FLOW
NO	OFF	OFF	NO
NO	OFF	ON	NO
NO	ON	OFF	NO
NO	ON	ON	YES
YES	OFF	OFF	NO
YES	OFF	ON	NO
YES	ON	OFF	NO
YES	ON	ON	NO

FIG. 3

Cancel

00EOT" 938/8960




FIG. 2

*Cancelled*




FIG. 4

*Cancel*

DETOT 98848960




FIG. 5